

MP3-01/2/3/5 Radio for Hyundai Vehicles. Remove and Refit Instructions.

This instruction covers all the above model numbers and their suffix variants.

1. Preparation.
Obtain the radio removal tool kit.



2. Insert the hook of the radio trim removal tool into the small hole between the radio front panel and attached frame trim. Pull the frame trim outward from the radio as shown. Remove the trim from the radio.



3. Insert the radio removal tool tapered edge into the gap between radio clip and the mounting frame as shown.



4. Push the tool into the gap until the edge of the tool is hard up and square against the radio front panel as shown. Repeat steps 3 and 4 for the opposite side of the radio.



5. Grasp each tool with each hand. Pull the tools outward from the dash equally so that the radio is released approximately 80 mm from the mounting frame as shown. Remove the tools from the radio sides.



6. Pull the radio out of the dash as shown to reveal the radio rear wiring connectors.

Once removed, carefully support the radio and ensure the vehicle dash and radio front is not at risk of damage during the next step.



7. Disconnect the wiring and antenna connectors. Each connector will incorporate a locking tab that must be depressed whilst the connector is pulled away from the radio. The round antenna plug is the only connector that does not have a locking tab.

8. Refitting is a reverse process but the removal tools are not required.
 - a. Attach wiring connectors.
 - b. Feed the wiring into the radio cavity and positioned so that the wiring is not crushed during the next step.
 - c. Fit the radio into the frame and push home until a click is heard from each side retaining clip.
 - d. Refit the trim frame so that it is neatly flush with the radio front.